

SUN TOUR POWER SHIFT LEVER PUB-10 · PUB-5

Assy No.	CODE NO.	PART NO.	NOMENCLATURE	REFERENCE COLUMN
1	3094 0512	1221	Lever frame	PUB-5 Type
1	3104 0512	1222	Lever frame	PUB-10 Type
2	3094 0601	1223	Lever axle	PUB-5 Type
2	3104 0601	1224	Lever axle	PUB-10 Type
3	3094 0521	1113	Lever clamp	
4	3000 5525	1114	Clamp screw	
5	3000 8451	1163	Friction washer	
6	3039 7011	1210	Ratchet spring	
7	3000 5331	1211	Set screw	
8	3039 7112	1207	Ratchet spring	
9	3000 8140	1028	Slot washer	
10	3039 1911	1213	Ratchet	
11	2000 8131	1214	Washer	
12	3070 02	1215	Lever rotation stop	Right side
13	3084 02	1215	Lever rotation stop	Left side
14	3094 7101	1216	Assembly pressure spring	
15	3074 0301	1217	Spring cover	
16	3134 3901	1060	Wing nut	
17	3000 5558	1061	Adjustment screw	
18	3039 0101	1208	Lever handle	Right side
19	3049 0111	1209	Lever handle	Left side
20	3039 3301	1246	Lever cap	
21	3000 8043	1218	Aluminum cover	
22	3000 5543	1319	Lock screw	

SUN TOUR LEVER UB-10 · UB-5

Assy No.	CODE NO.	PART NO.	NOMENCLATURE	REFERENCE COLUMN
3	3094 0521	1113	Lever clamp	
4	3000 5525	1114	Clamp screw	
16	3134 3901	1060	Wing nut	Plastic resin
17	3000 5558	1061	Adjustment screw	
35	3000 8454	1028	Lever bushing	
36	3054 0101	1801	Lever handle	For use on left or right side
37	3019 3311	1057	Lever cap	
38	3019 3911	1016	Assembly pressure plate	Plastic resin
39	3019 7101	1812	Assembly pressure spring	
40	3019 0301	1813	Cover	
41	3054 0411	1112	Lever frame	No.51 UB-5 Type
42	3054 0601	1111	Lever axle	No.52 UB-5 Type
43	3074 3911		Lever axle cap	For UB-5
44	3054 2121	1115	Bell clangor	
45	3000 5551	1116	Bell support post	
46	3054 2111	1119	Bell	
47	3000 5572	1117	Bell securing nut	